


Installation of equipment

IMPORTANT: It is essential to refer to the installation instructions for information on the size of the safety areas.

———— Impact area (minimum normative surface)

- - - - - Free space



1	0,6m	25,5m ²
2	0,97m	47m ²



2



14h00



1.1m³



72.5m²



1779kg



1650kg

EN

1176