


Installation of equipment

IMPORTANT: It is essential to refer to the installation instructions for information on the size of the safety areas.

———— Impact area (minimum normative surface)

- - - - Free space



1	1,00m	22,5m²



0



02h00



0.15m³



22.5m²



227kg



165kg

EN

1176